

Server Room Monitor

Protect your server room from outages with advanced environmental monitoring.



We've got server rooms covered.

Safeguard your server room from environmental threats by continuously monitoring temperature, humidity, power, water leaks, and other vital factors. With easy installation, user-friendly interfaces, and customizable alerts, the Data Center Monitor ensures compliance with industry standards and provides peace of mind for your organization. For more information and specifications, please visit RoomAlert.com.










RoomAlert
We've got this.

Room Alert PRO Server Room Monitor

Monitor temperature, humidity, power status, air flow, airborne particulate levels, water leaks, and unauthorized room access all from a single Room Alert bundle.

This essential bundle helps prevent equipment overheating, detect HVAC failures, identify power outages, catch water damage early, and alert you to security breaches before they impact your server room operations. The Room Alert 12SR monitor and complete sensor suite provide 24/7 protection with instant alerts and centralized monitoring through Room Alert Account, all at a discounted bundle price.

Product	Name	Description
	Room Alert PRO 12SR Monitor	Monitor multiple environment conditions with the Room Alert PRO 12SR monitor. 1U rackmountable with built-in temperature monitoring, 8 total sensor ports, and a relay output port.
	Digital Temp & Humidity Sensor	Monitor temperature, humidity, heat index, and dew point from one sensor.
	Particulate Sensor	Monitor airborne particulate matter (both PM 10 and PM 2.5) as well as temperature.
	Air Flow Sensor	Get instant air flow readings at any vent or duct, as well as temperature. Perfect for HVAC monitoring.
	Flood Sensor w/ Cable (8')	This sensor sends immediate alerts when water or liquid is detected anywhere along the sensing cable.
	Power Sensor	Monitor main power status to be alerted the moment power is lost to your facility.
	Room Entry Sensor	Place on main entry doors or on secure cabinet doors to be alerted when entry is gained.